

ReWorx Product Guidelines

ShawContract®

2023

ReWorx Product Guidelines

Notes for Cover Page:

ReWorx should be installed glued down with 4151, unless noted otherwise.

- *Every application is different, this document should be used as a guide, if you have specific questions or concerns unique to your space contact Shaw Contract Inforum for more assistance.*
- *All recommendations are made for running line products, if you have questions about a custom product please contact Shaw Contract Inforum.*
- **Entry Area, Foyers & Vestibules*** – Regardless of the flooring that is used in an Entry Area there should always be a walk-off mat or walk-off carpet tile at the doorway to absorb rain, salt and dirt. This will protect and extend the life of any floor.

